

Fig. 1




Fig. 2




Fig. 3

90





Fig. 4

102




104

Fig. 5

86

108

VIEW PRINTER STATUS



SOFTWARE
PROFILE/
SOFTWARE
MANAGEMENT

110

MEMORY
PROFILE/
MEMORY
MANAGEMENT

112

HARDWARE
PROFILE/
HARDWARE
MANAGEMENT

114

PRINTER
DIAGNOSTICS

116

Fig. 6

FIG. 7 is a schematic diagram of a user interface for managing print jobs. The interface includes a table with columns for Owner, Entry Time, Document Name, Status, and Document Size. Below the table is a large rectangular area for displaying job details. To the right of the details area is a button labeled "EDIT PRINT JOBS". The entire interface is enclosed in a rectangular frame.

120

ACCESS PRINT JOBS

OWNER	ENTRY TIME	DOCUMENT NAME	STATUS	DOCUMENT SIZE

122

124

EDIT
PRINT
JOBS

Fig. 7

126